



TAFML Series 2" Multimedia Filters

Sediment Filters

The Biolab TAFML 2" Series Multimedia Filter is designed to efficiently remove suspended solids and fine turbidity particles down to 15 micron from incoming water. Our complete system series features the Magnum IT™ valve with standard controller for simple operation and efficient backwashing.

Operating Parameters

- Pressure: 20-100 psi (138 - 690 KPA)
- Temperature: 35-100° F (2-38° C)
- Electrical: 115/60Hz, single phase
- Inlet/Outlet: 2.0 inch
- Drain: 1.5 inch

Standard Features

- Fully automatic backwash
- Flow rates up to 75 USgpm
- Flow rates up to 150 USgpm
- Durable, high quality Multi-layered media
- Less than 15 micron filtration
- Non-corroding fiberglass tank
- Valve constructed of plastic materials
- Standard reliable electronic timer

Typical Applications

- Reverse osmosis pretreatment
- Boiler feedwater
- Reagent grade laboratory water systems
- USP purified water systems
- Hemodialysis water systems
- Commercial water systems
- Food and beverage



Options Available

- Single, duplex twin alternating or parallel configs
- Free standing or skid-mounted systems
- Factory, fully pre-plumbed & pre-wired systems
- Custom installations and valve nests to meet facility requirements

Materials of Construction

- Media Tank: FRP - HDPE lined
- Control Valve: Glass filled Noryl®
- Media: Multi-layered with gravel bed
- Distributor Piping: PVC

TAFML Series 2" Sediment Filters @ 25°C

Model Number	Flow Design (USgpm)	Media Volume (Ft. ³)	Backwash Flow (USgpm)	Pressure Drop @ Peek (psig)	Media Tank W x H (In.)	Shipping Weight (Lbs.)	Space Requirements W x D x H
TAFML-1865M	25	5	25	5	18 x 65	475	18 x 18 x 74
TAFML-2162M	36	7	35	7	21 x 62	675	21 x 21 x 74
TAFML-2472M	47	10	45	12	24 x 72	1040	24 x 24 x 84
TAFML-3072M	78	15	75	17	30 x 72	1335	30 x 30 x 84

Note: All weights and dimensions are approximate. Duplex, Parallel and Triplex systems are available.

Installation Considerations

- For proper serviceability, it is recommended that there be 18" of space around the entire system. A minimum of 12" is required. The tanks should be installed on a firm, level surface.
- The inlet piping should be sized large enough to provide the required water flow for both service flow and backwashing of the tanks with minimum amount of pressure loss.
- A drain with suitable capability for the backwash flow rate of the tanks is required.
- Isolation valves, pressure gauges, sample ports, a vacuum breaker and a relief valve should be installed on each assembly.

For More Information

- Contact one of our application specialists at USA (800) 346-0365 or Canada (800) 268-5035, or visit www.mcpur.com

Noryl is a registered trademark of GE. Performa is a trademark of GE Infrastructure Water and Process Technologies.

Mar Cor Purification
4450 Township Line Road
Skipack, PA 19474-1429
U.S.A.
Tel: (484) 991-0220
Toll Free: (800) 346-0365
Fax: (484) 991-0230

Mar Cor Purification
14550 28th Avenue North
Plymouth, MN 55447
U.S.A.

Toll Free: (800) 633-3080

Mar Cor Purification
3250 Harvester Road - Unit 6
Burlington, ON L7N 3W9
Canada

Tel: (905) 639-7025

Toll Free: (800) 268-5035

Fax: (905) 639-0425

Minntech B.V.

Sourethweg 11

6422 PC Heerlen

The Netherlands

Tel: (+31) 45 5471 471

Fax: (+31) 45 5429 695

Minntech Asia/Pacific Pte. Ltd.

438 Alecandra Road

#03-01 Alexandra Point

Singapore 119958

Tel: (+65) 6227 9698

Fax: (+65) 6225 6848