

Portable Exchange Carbon

Activated Carbon Tanks

Portable Exchange Carbon is an economical and efficient process for removing chlorine, chloramines and dissolved organic contaminants from incoming water supplies. Our portable exchange tanks contain virgin carbon to assure maximum water quality and service life.

These portable exchange tanks provide greater flexibility than permanent systems by delivering treated water where you need it. This custom approach provides consistent water quality when resources and budgets are limited. These units are excellent for low flow rates, limited water quantities, or just temporary requirements. Your involvement is minimal because our local service technicians handle the removal and replacement keeping you with a constant supply of treated water with no on-site chemicals.

Mar Cor Purification is committed to quality control. From materials, to methods, to documentation, all of our processes are designed to produce consistent and compliant products each and every time assuring our customers the highest quality water and performance from each filled carbon tank and each regenerated deionizer. For critical medical applications our Carbon and SDI systems are prepared in FDA registered facilities in accordance with QSR/GMP (Quality System Regulations/Good Manufacturing Practices) requirements.

Tank Specifications

- Construction Fiberglass
- Head..... PVC
- Internals PVC
- Fittings..... See Chart
- Media Acid Washed Carbon
12x40 mesh, Iodine #1000



Operating Parameters

- Max. Operating Pressure & Temperature
0.25 - 3.6 ft³ 90 psi/100°F
- Turbidity..... 5 NTU
- Color..... 5 units
- Organics 3 ppm
- Manganese and Iron 0.3 ppm

Typical Applications

- General Industry
- Hemodialysis and Life Sciences
- Laboratory
- Microelectronics
- Rinsing
- Pharmaceutical/Biotech

Portable Exchange Carbon Specifications

Model Number	Max. Flow Rate USGPM (LPM)	Carbon Volume (ft ³)	Inlet / Outlet Ports	Dimensions W x H (Inch)	Weight (Wet) Lbs. (kg)
6 x 18C	2.0 (7.6)	0.25	SIDE 3/4" MGHT	7 x 20	25 (11.3)
8 x 18C	2.0 (7.6)	0.50	SIDE 3/4" MGHT	9 x 20	32 (14.5)
6 x 35C	2.5 (9.5)	0.50	SIDE 3/4" MGHT	7 x 37	73 (33.1)
8 x 35C	2.5 (9.5)	0.85	SIDE 3/4" MGHT	9 x 37	95 (43.1)
8 x 44C	4.0 (15.1)	1.25	SIDE 3/4" MGHT	9 x 46	135 (61.3)
12 x 36C	7.0 (26.5)	2.20	TOP 3/4" MGHT	13 x 38	198 (89.9)
14 x 47C	10.0 (37.9)	3.60	TOP 1" QD	15 x 52	305 (138.5)

Note: All weights and dimensions are approximate. Higher flow rates can be obtained with parallel configurations. Jumbo tanks are available upon request.

Accessories Available

- Pre and post filters
- Sample ports
- Pressure regulators
- Water meters
- Pressure gauges
- Ultraviolet lights

Installation Considerations

- System operates on tap pressure, within a pressure range of 25-60 psi and a maximum pressure of 90 psi.
- The system must be installed on a firm, level surface.
- A floor drain is recommended.
- Accessories may require electrical connections.

Service Policy

Mar Cor Purification offers carbon exchange services. This service is conducted at Mar Cor Purification owned and operated facilities in Philadelphia, Atlanta, Boston, Los Angeles, and Chicago. Our facilities only handle carbon that has a 12x40 mesh size with an iodine number of at least 1000. The carbon is acid-washed, virgin; GAC made from select bituminous coal. Mar Cor Purification does not reuse carbon at any time during its processes. All tanks are considered rental and will remain the property of Mar Cor Purification unless structured otherwise. We offer 24/7 service from any of our US service centers.

Hemodialysis

For dialysis applications, Mar Cor Purification recommends that 2 carbon tanks sized for 5 minutes of empty bed contact time each are used and that daily samples are taken from a testport located in between the two tanks. $EBCT = (VGAC \times 7.48) / \text{flow rate in GPM}$.

Mar Cor Purification
4450 Township Line Road
Skipack, PA 19474-1429
U.S.A.

Tel: (484) 991-0220
Toll Free: (800) 346-0365
Fax: (484) 991-0230

Mar Cor Purification
14550 28th Avenue North
Plymouth, MN 55447
U.S.A.

Tel: (484) 991-0220
Toll Free: (800) 633-3080
Fax: (763) 210-3868

Mar Cor Purification
3250 Harvester Road - Unit 6
Burlington, ON L7N 3W9
Canada

Tel: (905) 639-7025
Toll Free: (800) 268-5035
Fax: (905) 639-0425

Minntech B.V.
Sourethweg 11
6422 PC Heerlen
The Netherlands

Tel: (+31) 45 5471 471
Fax: (+31) 45 5429 695

Minntech Asia/Pacific Pte. Ltd.
438 Alecandra Road
#03-01 Alexandra Point
Singapore 119958

Tel: (+65) 6227 9698
Fax: (+65) 6225 6848