

Pretreatment - Sediment Filters

TAFMZ Series, 2" Sediment Filter

The Biolab TAFMZ 2" Series Sediment Filter is designed to efficiently remove suspended solids and fine turbidity particles down to 5 micron from incoming water.

Our complete system series features the Magnum IT™ valve with standard controller for simple operation and efficient backwashing.

Operating Parameters

- Pressure: 20-100 psi (138 - 690 KPA)
- Temperature: 35-100° F (2-38° C)
- Electrical: 115/60Hz, single phase
- Inlet/Outlet: 2.0 inch
- Drain: 1.5 inch

Materials of Construction

- Media Tank: FRP - HDPE lined
- Control Valve: Glass filled Noryl®
- Media: Micro Z with gravel bed
- Distributor Piping: PVC

Standard Features

- Fully automatic backwash
- Flow rates up to 75 USgpm
- Parallel flow rates up to 150 USgpm
- Durable, high quality Micro Z™ media
- Less than 5 micron filtration
- Non-corroding fiberglass tank
- Valve constructed of plastic materials
- Standard reliable electronic timer
- Up to 2 x loading capacity compared to standard multimedia (reduced backwash frequency)



Options Available

- Single or parallel configurations
- Free standing or skid-mounted systems
- Factory, fully pre-plumbed & pre-wired systems
- Custom installations and valve nests to meet facility requirements

Typical Applications

- Reverse osmosis system pretreatment
- Boiler feedwater
- Reagent grade lab water systems
- USP purified water systems
- Hemodialysis & Life Sciences water systems
- Commercial & Industrial water systems
- Food and Beverage Industry

TAFMZ Series 2" Sediment Filters @ 25°C

Model Number	Flow Design (USgpm)	Media Volume (Ft. ³)	Backwash Flow (USgpm)	Pressure Drop @ Peek (psig)	Media Tank W x H (In.)	Shipping Weight (Lbs.)	Space Requirements W x D x H (In)
TAFMZ-1865M	25	5	25	3	18 x 65	600	18 x 18 x 84
TAFMZ-2162M	40	7	35	7	21 x 62	675	21 x 21 x 84
TAFMZ-2472M	50	10	45	12	24 x 72	1040	24 x 24 x 99
TAFMZ-3072M	75	15	70	17	30 x 72	1335	30 x 30 x 99

Note: All weights and dimensions are approximate.

Installation Considerations

- For proper serviceability, it is recommended that there be 18" of space around the entire system. A minimum of 12" is required. The tanks should be installed on a firm, level surface.
- The inlet piping should be sized large enough to provide the required water flow for both service flow and backwashing of the tanks with minimum amount of pressure loss.
- A drain with suitable capability for the backwash flow rate of the tanks is required.
- Isolation valves, pressure gauges, sample ports, a vacuum breaker and a relief valve should be installed on each assembly.

For More Information

Contact one of our application specialists at USA (800) 346-0365 or Canada (800) 268-5035, or visit www.mcpur.com

Noryl is a registered trademark of GE. Performa is a trademark of GE Infrastructure Water and Process Technologies.



Mar Cor Purification
4450 Township Line Road
Skipack, PA 19474-1429
Tel: (484) 991-0220
Toll Free: (800) 346-0365
Fax: (484) 991-0230

Mar Cor Purification
14550 28th Avenue North
Plymouth, MN 55447
Tel: (484) 991-0220
Toll Free: (800) 633-3080
Fax: (763) 210-3868

Mar Cor Purification
3250 Harvester Road - Unit 6
Burlington, ON L7N 3W9
Tel: (905) 639-7025
Toll Free: (800) 268-5035
Fax: (905) 639-0425

Mar Cor Purification
Sourethweg 11
6422 PC Heerlen
The Netherlands
Tel: (+31) 45 5471 471
Fax: (+31) 45 5429 695

Mar Cor Purification
1A International
Business Park, #05-01
Singapore 609933
Tel: (+65) 6227 9698
Fax: (+65) 6225 6848